

EPSON
EXCEED YOUR VISION


Home Cinema
EH-TW6000W
EH-TW6000
EH-TW5900





EN	Quick Start Guide
DE	Kurzanleitung
FR	Guide de démarrage rapide
IT	Guida di avvio rapido
ES	Guía de inicio rápido
PT	Guia de Referência Rápida
NL	Introductiehandleiding
DA	Introduktion
FI	Pika-aloitusopas
NO	Hurtigveiledning
SV	Snabbstartsguide
CS	Úvodní příručka
HU	Bevezetés
PL	Przewodnik szybkiego startu
EL	Οδηγός γρήγορης εκκίνησης
TR	Hızlı Başlangıç Kılavuzu
RU	Руководство по быстрой установке
AR	دليل البداية السريعة
ZHS	设定手册


1
















EH-TW6000W/EH-TW6000 only











EH-TW6000W only


2



HDMI 1
HDMI 2
Service Only
Video
Y
Cb/
Pb
L
Audio
R
Cr/Pr
Component
PC
RS-232C
External 3D IR


HDMI1
HDMI2
HDMI
HDMI


HDMI 1
HDMI 2
Service Only
Video
Y
Cb/
Pb
L
Audio
R
Cr/Pr
Component
PC
RS-232C
External 3D IR



Video
L
Audio
R
VIDEO
AUDIO OUT
(L, R)


HDMI 1
HDMI 2
Service Only
Video
Y
Cb/
Pb
L
Audio
R
Cr/Pr
Component
PC
RS-232C
External 3D IR


Component
Y
Cb
/Pb
Cr/Pr
L
Audio
R
Y
Cb/Pb
Cr/Pr
AUDIO OUT
(L, R)


3

16:9




4

ON




2 ON
1
3 ON
On
Standby
Source
USB
HDMI2
WirelessHD
Component
Video
PC


OFF




1 OFF
On
Standby
USB
WirelessHD
Component
Video
PC
2


5







6









Printed in China

412152300